



GBK-S and GFK-S bench and floor checkweighing scales offer bright, clear displays, heavy-duty durability, advanced checkweighing functions and a wide range of capacities and base sizes. Their 5-key operation makes general weighing tasks easy, with weight readings appearing clearly in 40mm-high digits. For checkweighing tasks, the backlight changes color to denote whether the sample is under (amber), over (red) or within (green) preset limits. Weighing results can be exported via the RS-232 port to a PC or printer.

*Simple, straightforward weighing for demanding industrial environments*



## Features

- Color-changing backlight in checkweighing mode to show if under, over or within acceptable limits
- Large, 40mm-high easy to read digits on a bright background
- Simple, 5-key operation allows for easy set up and use
- Solid ABS housing (Indicator) is durable for industrial use
- Large, grade 304 stainless steel pan allows swift cleaning
- RS-232 interface provides speedy connection to computers and printers
- Optional USB interface simplifies data communication
- Selectable language for printing
- 1:1,600,000 Internal counting resolution for precise results
- Auto power-off to save energy
- Hold function freezes the displayed weight, allowing time to elapse without losing the result
- External calibration allows for verification and adjustment with weights
- Capacity tracker built into display for easily monitoring possible overloads

## Applications

- Weighing
- Parts counting
- Percentage weighing
- Checkweighing
- Check counting
- Accumulation

### About ADAM:

For more than 50 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

## Product Details

Model	GBK-S 8	GBK-S 16	GBK-S 32	GBK-S 60	GBK-S 120	GFK-S 75H	GFK-S 75	GFK-S 150H	GFK-S 150	GFK-S 300	GFK-S 600
Capacity	8kg	16kg	32kg	60kg	120kg	75kg		150kg		300kg	600kg
Readability	0.1g	0.5g	1g	2g	5g	1g	5g	2g	0.01kg	0.02kg	0.05kg
Weighing Units	g, kg, lb, oz, lb:oz										
Internal Counting Resolution	1:1,600,000										
Interface	RS-232, Optional USB										
Calibration	External										
Display	Backlit LCD with 40mm-high digits										
Power Supply	12VDC 800mA adapter, Optional internal rechargeable battery										
Operating Temperature	-10° to 40°C										
Housing	ABS Plastic indicator with die-cast aluminium base										
Overall Dimensions (DxWxH)	300 x 510 x 680mm					400 x 620 x 860mm				600 x 940 x 900mm	

## Accessories

### Item Number.....Description

- 3052010526 ..... In-use wet cover
- 3074010266 ..... RS-232 cable
- 3074010507 ..... RS-232 to USB adapter
- 1120015779 ..... ATP2 Thermal Printer
- 3126011263 ..... ATP2 paper
- 3126011281 ..... ATP2 paper (x10)
- 600002028 ..... AdamDU Data Collection Program
- 700660290 ..... Calibration certificate
- 1140013826 ..... Roller deck (15.7" x 11.8")
- 1140013827 ..... Roller deck (19.7" x 15.7")
- 1140013828 ..... Roller deck (31.5" x 23.6")

## Key Accessories



### ATP2 Thermal Printer

The ATP2 is a compact general purpose thermal roll printer that connects via RS-232 interface, printing results quickly and easily.



### AdamDU Data Collection Program

Adam DU quickly collects information from up to eight Adam balances simultaneously. An easy-to-use interface with a main command window allows the user to view and manage data capture sessions.

Supplied by

Adam Equipment follows a policy of continuous improvement and reserves the right to change specification and pricing without notice. Adam Equipment's standard terms and conditions of sale apply. Errors and omissions excepted.