



Combining durability and performance, Gladiator scales achieve washdown weighing tasks in the most demanding food, pharmaceutical and industrial applications. With an IP68 rating for washdown capabilities, Gladiator features easy-to-clean stainless steel construction that is ideal for wet and dusty environments. Connectors on the bottom are IP68-rated for thorough protection. Gladiator expedites checkweighing with a large, backlit display that changes colour to show if the weight is over, under or within the set limit. Designed for maximum efficiency, Gladiator features a tactile keypad with large, colour-coded keys for easy operation. EC type approval means the Gladiator is suitable for use in legal for trade applications.

## IP68 rating means industrial-strength washdown protection



### Features

- Backlit display changes colour for quick notification of checkweighing limits
- Large, grade 304 stainless steel pan allows easy cleaning
- Rugged stainless steel housing for ultimate durability
- Heavy-duty rubber feet ensure stability of unit
- Sealed keypad protects against dirt and spills
- Colour-coded keys facilitate quick recognition of the most frequently used buttons
- RS-232 interface is available to provide speedy connection to computers and printers
- External calibration allows for verification and adjustment with weights
- Hold function freezes the displayed weight, allowing time to elapse without losing the result
- Parts counting with preset sample sizes
- Selectable digital filtering for animal/dynamic weighing enables consistent results for moving subjects
- EC type approved
- IP68-rated for protection against water and dust
- Rechargeable battery included for operation almost anywhere
- Programmable auto power-off to save energy

### Applications

- Weighing
- Parts counting
- Percentage weighing
- Checkweighing
- Check counting
- Display hold
- Peak hold
- Dynamic / animal weighing
- Net/gross

### About ADAM:

For more than 50 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

## Product Details

Model	GG8	GG16	GG35	GG35	GG75	GG75	GG75H	GG150	GG150	GG300	GG6M	GG15M	GG30M	GG30M	GG60M	GG60M	GG150M	GG150M	GG300M	
<b>Capacity</b>	8kg	16kg	35kg	35kg	75kg	75kg	75kg	150kg	150kg	300kg	6kg	15kg	30kg	30kg	60kg	60kg	150kg	150kg	300kg	
<b>Readability</b>	0.2g	0.5g	1g	1g	2g	2g	1g	5g	5g	0.01kg	2g	5g	0.01kg	0.01kg	0.02kg	0.02kg	0.05kg	0.05kg	0.1kg	
<b>Repeatability (S.D.)</b>	0.4g	1g	2g	2g	4g	4g	2g	10g	10g	0.02kg	4g	10g	0.02kg	0.02kg	0.04kg	0.04kg	0.1kg	0.1kg	0.2kg	
<b>Linearity (+/-)</b>	0.4g	1g	2g	2g	4g	4g	2g	10g	10g	0.02kg	4g	10g	0.02kg	0.02kg	0.04kg	0.04kg	0.1kg	0.1kg	0.2kg	
<b>Pan Size</b>	250x250mm		300x400mm		400x500mm			450x600mm			250x250mm		300x400mm		400x500mm		450x600mm			
<b>Weighing Units</b>	g, kg, lb, lb:oz, oz, N, custom unit										g, kg									
<b>Stabilisation Time (sec)</b>	2																			
<b>IP Rating</b>	68																			
<b>Interface</b>	Optional RS-232																			
<b>Calibration</b>	External calibration																			
<b>Display</b>	Backlit LCD with 40mm -high digits																			
<b>Power Supply</b>	Internal rechargeable battery / Mains power cord																			
<b>Operating Temperature</b>	0° to 40°C																			
<b>Housing</b>	Stainless steel																			
<b>Overall Dim.</b>	250x351x575mm (wxdxh)		300x523x-662mm (wxdxh)		400x605x1032mm (wxdxh)			450x702x-1032mm (wxdxh)			250x351x575mm (wxdxh)		300x523x-662mm (wxdxh)		400x605x-1032mm (wxdxh)		450x702x-1032mm (wxdxh)			
<b>Net Weight</b>	6.80kg		10.42kg		13.06kg			21.09kg			6.80kg		10.42kg		13.06kg		21.09kg			
<b>Approvals</b>	N/A										EC type approved									

### Accessories

Item number	Description
1120011156	ATP thermal printer
3074010507	RS-232 to USB adapter (must order corresponding RS-232 cable)
1100011297	Relay box
600002028	AdamDU Data Collection Program
700660290	Calibration certificate
1120014641	AIP impact printer
3134012936	RS-232 Cable to 9pin D connector 1.5m (factory fitted)
3134012941	RS-232 Cable to ATP Printer 1.5m (factory fitted)
3074010266	RS-232 cable (null-modem)

### Key Accessories



**AIP Impact Printer**  
Easy to use, the AIP high-speed dot matrix printer connects with any device containing an RS-232 or USB interface. Communication is smooth and fast, as the AIP automatically detects a scale's settings. AIP features durable ABS plastic construction and is simple to use, as it operates with just an on/off switch and a paper feed button.



**Relay Box**  
The relay box is connected by wire to the scale, and helps transmit signals to other devices.

### Supplied by